



Basic Connection

Coaxial / RF Cable / Antenna



Connect Power Cord




Press the **POWER** button on the remote control to turn on the TV

QUICK START GUIDE



Simple Steps for Connecting  
your TV to A/V Devices



**IMPORTANT NOTE:**

During setup, do NOT run the “Channel Auto Scan” function if your TV is connected to a Cable or Satellite set top box.


For technical support, the VIDAO Technical Support Center is available 10:00AM to 7:00PM (Monday to Saturday) for technical assistance or troubleshooting. To contact us by phone, please call 1-855-998-4326.

**A/V Devices Include:**

- Blu-ray® Disc Players
- DVD Players
- Cable, Satellite, or Set-Top Boxes
- VCRs
- Game Consoles

If you need additional  
help, please consult  
your user manual.

**Insert the TV into the base and securely attach.  
Install the batteries in the Remote Control**



Stand Receiver shape may differ, but stands assemble the same.  
Use the enclosed screws to secure the stand.




To operate this TV using the remote control provided by your Cable / Satellite provider, follow the programming instructions included with the providers' remote control and input the following codes when prompted;

- For Comcast or DirectTV remote controls, input the code- 10030.
- For AT&T ( U-verse ) remote Controls, input the code- 1043.
- For RCA Universal Remote Controls, input the code- 0030.
- For Dish Network remote controls, input the code- 506.


## HDMI

**Best  
Connection**



## Component

**Better  
Connection**



**For technical support, the VIDAQ Technical Support Center is available 10:00AM to 7:00PM (Monday to Saturday) for technical assistance or troubleshooting.  
To contact us by phone, please call 1-855-998-4326.**

## Composite

**Good  
Connection**

