

Model: ANT1800

360° AMPLIFIED OMNIDIRECTIONAL HDTV ANTENNA



INSTRUCTION MANUAL

For technical assistance or troubleshooting please call 1-855-998-4326 or visit www.sibrandssupport.com


INSTRUCTION MANUAL

POWER

This antenna can be powered by either the included AC power adapter, or by connecting the included USB power cable to a Laptop or PC. It is not necessary to connect both cables to power the antenna.

AC Power Connection

Connect the supplied AC adapter cable to the back of the Antenna. Connect the AC adapter to a standard AC outlet.




USB Power Connection

Connect one end of the supplied USB power cable to the back of the Antenna.

Connect the other end of the USB power cable to an open USB port on your Laptop or PC.

Now the USB Cable can power the TV Antenna.

Note: Contact your PC manufacturer to check if there are any software updates needed for this operation.




Connect to TV

Connect the end of attached coaxial cable to the TV's RF input socket.



Adjusting the Antenna

This 360° Omnidirectional Antenna should not require moving positions to find the best reception. In some locations where signals may be very weak, try to re-position the antenna for the best signal.





LIMITED 90-DAY WARRANTY

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized VIDAO dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

Our Customer Support Center is available Monday - Saturday (10:00AM to 7:00PM EST) for technical assistance or troubleshooting. To contact us, please call 1-855-998-4326 or visit www.sibrandssupport.com

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product. Damage to any external media such as DVD & CD discs, and/or USB or other memory devices are not covered nor is the cost incurred in shipping the unit for warranty repair or exchange. Under no circumstances shall VIDAO be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

UNDER NO CIRCUMSTANCES WILL VIDAO BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.

Schoenfeld International Inc and VIDAO 5001 American Boulevard West Suite 275
Bloomington, Minnesota 55437

©Schoenfeld International Inc., 2017 ANT1800 Ver. 1.0 July 2017