
24E800LC

Basic Connection	Coaxial / RF Cable / Antenna	
	HDMI(MHL) CABLE/ANTENNA A LOO ROUTJ	
	AV DEVICE Cable not included	


Connect Power Cord



Press the POWER button on the remote control to turn on the TV

QUICK START GUIDE

Simple Steps for Connecting your TV to A/V Devices



IMPORTANT NOTE:

For technical support, the ETEC Technical Support Center is available 10:00AM to 7:00PM (Monday to Saturday) for technical assistance or troubleshooting. To contact us by phone, please call 1-855-994-3832.



"HDMI", the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC." "Blu-ray Disc" is a trademark of Blu-ray Disc Association, registered in the U.S. and other countries. All other trademarks are the property of their respective owners.

During setup, do NOT run the "Channel Auto Scan" function if your TV is connected to a Cable or Satellite set top box.

If you need additional help, please consult your user manual.

Insert the TV into the base and securely attach. Install the batteries in the Remote Control

