55V850

Basic Connection

Coaxial / RF Cable / Antenna

TV

HDMI 2 (MHL)   HDMI 3 (ARC)   VGA   PC AUDIO   CABLE-ANTENNA   USB

A/V DEVICE

Cable not included

Connect Power Cord

TV

Press the POWER button on the remote control to turn on the TV

IMPORTANT NOTE:
During setup, do NOT run the "Channel Auto Scan" function
if your TV is connected to a Cable or Satellite set top box.

For technical support, the VIDAO Technical Support Center is available 10:00AM
to 7:00PM (Monday to Saturday) for technical assistance or troubleshooting.
To contact us by phone, please call 1-855-998-4326.

A/V Devices Include:

• Blu-ray® Disc Players
• DVD Players
• Cable, Satellite, or Set-Top Boxes
• VCRs
• Game Consoles

**If you need additional
help, please consult
your user manual.**

Insert the TV into the base and securely attach.
Install the batteries in the Remote Control

Stand Base & Post may vary but assembly is the same.
Use the 6 enclosed screws to secure the base to the post.

To operate this TV using the remote control provided by your Cable / Satellite provider, follow the programming instructions included with the providers' remote control and input the following codes when prompted;
-For Comcast or DirecTV remote controls, input the code- 10030.
-For AT&T (U-verse) remote Controls, input the code- 1043.
-For RCA Universal Remote Controls, input the code- 0030.
-For Dish Network remote controls, input the code- 506.

Best Connection

HDMI

TV

V Y Pb Pr
YPbPr   HDMI1

HDMI2 (MHL)   HDMI3 (ARC)   VGA

HDMI cable not included

A/V DEVICE

Better Connection

Component

TV

COAXIAL OUT   L R   V Y Pb   Pr
AV   YPbPr   HDMI 1

Component cables not included

AV DEVICE

For technical support, the VIDAO Technical Support Center is available 10:00AM to 7:00PM (Monday to Saturday) for technical assistance or troubleshooting.
To contact us by phone, please call 1-855-998-4326.

Good Connection

Composite

TV

COAXIAL OUT   L R   V Y Pb   Pr
AV   YPbPr   HDMI 1

AV DEVICE