


BLUESTREAM
BSNB01-BSNB02 USER MANUAL



CHARGING

The headphones come with a built-in rechargeable battery. Before using for the first time, we recommend fully charging the battery.

- To Charge simply connect the supplied USB cable to a computer or any USB charger and to the USB Charging Port on the headphones.
- The LED light will turn RED while the headphones are charging.
- When the battery is fully charged the RED light will turn BLUE.
- A full charge normally takes around 2-3 hours.
- When the battery is low, the LED will flash and you will hear a voice prompt announcing that the battery is low.

CONTROLS

- **TURN ON:** Press and Hold the Power/Play/Pause button until the LED flashes Blue
- **TURN OFF:** Press and Hold the Power/Play/Pause button until the LED flashes Red
- **PLAY/PAUSE:** Press the Power/Play/Pause button once to Play. Press the Power/Play/Pause button again during playback to Pause. Press again to resume playback.
- **ANSWER/END CALL:** Press the Power/Play/Pause button once to Answer, press the Power/Play/Pause button again to End the call.
- **NEXT SONG:** Press the Volume + / Next song button once.
- **PREVIOUS SONG:** Press the Volume - / Previous Song button once.
- **RAISE VOLUME:** Press and Hold the Volume + / Next song button.
- **LOWER VOLUME:** Press and Hold the Volume - / Previous song button.

PAIRING TO YOUR DEVICE

1. Go to the "Bluetooth" Settings Menu on your device (phone, tablet, etc.)
2. Make sure that the "Bluetooth" function is turned ON.
3. Set the headphones to Pairing Mode by pressing and holding the Power/Play/Pause button until the LED flashes Red & Blue.
4. On the Bluetooth Device List on your device (phone, tablet, etc.) select "BSNB01 / BSNB02"
5. A voice prompt will signal that you are now Connected, and the LED will slowly flash Blue.

TROUBLESHOOTING

If the headphones are not pairing with your device properly, turn the Bluetooth function on your device OFF and also turn the headphones OFF. Wait few seconds, then turn the Bluetooth function on your device back ON, then turn the headphones ON and follow the Pairing instructions again.

LIMITED 90-DAY WARRANTY

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized BLUESTREAM dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

Our Customer Support Center is available Monday - Saturday (10:00AM to 7:00PM EST) for technical assistance or troubleshooting. To contact us, please call 1-855-719-8324 or visit www.sibrandsupport.com

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product, including the antenna. Damage to any external media such as DVD & CD discs, and/or USB or other memory devices are not covered nor is the cost incurred in shipping the unit for warranty repair or exchange. Under no circumstances shall BLUESTREAM be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

UNDER NO CIRCUMSTANCES WILL BLUESTREAM BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.