

Charging the Battery

Before using the headphones, fully charge the battery by plugging the provided cable into the Charging Port on the headphones, and a USB power source (not included). The LED Indicator will turn RED when the headphones are charging. The LED Indicator will turn OFF when the battery is fully charged.

Power

1. Power ON your headphones:

Press and Hold the Multifunction button for about 3 seconds. You will hear a short beep, and the LED will flash BLUE.

2. Power OFF your headphones:

Press and Hold the Multifunction button for about 3 seconds. You will hear a short beep, and the LED will flash RED.

Pairing the Headphones:

1. Turn your phone **OFF** entirely and then turn it back **ON** to refresh its Bluetooth memory.
2. Find the Bluetooth menu on your Bluetooth device and turn the Bluetooth function **ON** (Check your Bluetooth device's user guide for instructions on finding the Bluetooth menu)
3. With the headphones OFF, hold the headphones 12" inches away from your Bluetooth device and Press and Hold the Multifunction button for about 6 seconds until the LED Indicator flashes blue and red alternating which indicates your headphones are in PAIRING MODE and are now ready to be "paired" with your Bluetooth device.
4. On your Bluetooth device, perform a Bluetooth "device discovery" to add the headphones as a new device.
5. When the headphones are discovered (found) the device will display "**BSPRT01-2-3**" in the menu. Choose/Tap on "**BSPRT01-2-3**".
6. If prompted by your device to enter a code, enter; "**0000**" and the device will now pair with the headphones and be ready to use.
7. If supported by your phone menu, set the **BSPRT01-2-3** as "set as authorized" or "add to trusted devices".
8. Keep the Bluetooth function on your phone **ON** with your phone near, and the headphones will automatically pair.
9. If the pairing is not successful, the headphones will shortly return to the standby mode. Please repeat the process to try pairing again.
10. Refer to your Bluetooth device's User Manual for any additional steps or special features for your device.
11. To pair a second device, turn the first device's Bluetooth function **OFF**, then repeat steps 3-10 using the second device. Turn the headset **OFF**. Turn the first device's Bluetooth function back **ON**. Then turn the headset back **ON**. Both devices should automatically pair.

Note: To conserve power, the unit automatically turns off when not paired with your Bluetooth Phone.

For Assistance please call 1-855-719-8324. Do NOT return this product to your retailer.

Operating the Headphones:

1. To ANSWER or END a call:

Press the Multifunction button once when there is an incoming call to answer. Press the Multifunction button once again to end the call.

2. To REJECT* a call:

Press and Hold the the Multifunction button (approx. 2 seconds) when there is an incoming call you want to ignore/send to voicemail.

3. To REDIAL* the last call:

Press the Multifunction button twice while the headset is in "Standby mode" (not currently on a call or listening to music).

4. To adjust the VOLUME:

Press the **VOL+** button to Increase Volume. Press the **VOL-** button to Decrease Volume.

5. To PLAY/PAUSE music:


While listening to music, press the Multifunction button once to Pause playback. Press the Multifunction button once again to resume.

6. To change the SONG / TRACK:

To Skip to the Next Song Press and Hold the **VOL+** button. To Skip to the Previous Song Press and Hold the **VOL-** button.


Disconnecting the Headset:

To Disconnect or Unpair your device from the headphones go to the Bluetooth menu on your device and choose Disconnect under BSPRT01-2-3. Refer to your phone/device's instruction manual for instructions on finding the Bluetooth Menu and any additional steps for disconnection.



* To use these functions, your phone/device must also support the Bluetooth Profile.

ALL Controls & Microphone are located on the RIGHT Earphone



BLACKSTREAM

LIMITED 90-DAY WARRANTY

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized BLACKSTREAM dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

Our Customer Support Center is available Monday - Saturday (10:00AM to 7:00PM EST) for technical assistance or troubleshooting. To contact us, please call 1-855-719-8324 or visit www.sibrandssupport.com

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product, including the antenna. Damage to any external media such as DVD & CD discs, and/or USB or other memory devices are not covered nor is the cost incurred in shipping the unit for warranty repair or exchange. Under no circumstances shall BLACKSTREAM be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

UNDER NO CIRCUMSTANCES WILL BLACKSTREAM BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.