


Retro Flip Alarm Clock

MODEL: CH1200/1/2



COMPONENT IDENTIFICATION




1. TIME SETTING KNOB
2. ALARM SETTING KNOB
3. ALARM BUTTON
4. BATTERY COMPARTMENT COVER
5. STAND

POWER

This Alarm Clock is powered by one 'AA' battery.

1. Turn the Alarm Clock upside-down and open the Battery Compartment by gently pushing the locking tab on the Battery Compartment Cover toward the battery compartment while lifting the cover away from the clock.



2. Insert one 'AA' battery (not included) into the Battery Compartment.
 - Be sure to place the battery in the same polarity (+ or -) direction indicated on the engraved diagram inside the Battery Compartment.

SET THE CURRENT TIME

Before setting the time, make sure the clock is placed on a flat surface to insure the numbers flip correctly.

To set the current time turn the **TIME SETTING KNOB (1)** counterclockwise until the correct time is displayed.

- **NOTE:** AM & PM are shown on the Hour numbers.


SET THE ALARM TIME

To set the alarm time turn the **ALARM SETTING KNOB (2)** counterclockwise until the desired time is shown in the Alarm Window on the front of the clock.

- We recommend testing the alarm a couple times before using to understand the slight variance between the Alarm Time shown in the window to the actual time the alarm sounds so your alarm setting will be as accurate as possible.
- **NOTE:** Do not turn the **ALARM SETTING KNOB (2)** clockwise or the alarm will not set properly.
- **NOTE:** The alarm cannot be set for more than 12 hours ahead of the current time as the Alarm Time Setting does not recognize AM or PM.

TURN THE ALARM ON & OFF

The **ALARM BUTTON (3)** has two settings as shown in the image below.

ALARM ON = 

ALARM OFF = 

- To turn the ALARM ON: Press the **ALARM BUTTON (3)** once so the button is in the outward position as shown above.
- To turn the ALARM OFF: Press the **ALARM BUTTON (3)** once so the button is in the inward position as shown above.

TROUBLESHOOTING

ALARM NOT WORKING

- Make sure you have correctly set the Alarm Time.
- The alarm cannot be set for more than 12 hours ahead of the current time.
- Make sure you have turned the Alarm ON by pressing the **ALARM BUTTON (3)** so the button is in the outward position.

TIME NOT CHANGING

- Replace the battery.



LIMITED 90-DAY WARRANTY

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized CAPEHART dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

Our Customer Support Center is available Monday - Saturday (10:00AM to 7:00PM EST) for technical assistance or troubleshooting. To contact us, please call 1-855-998-4278.

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product. Under no circumstances shall CAPEHART be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

UNDER NO CIRCUMSTANCES WILL CAPEHART BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.