




# A5BS BLUETOOTH SPEAKER INSTRUCTION MANUAL

## CHARGING THE BATTERY

Before using the **A5BS**, fully charge the speaker by plugging the Micro USB end of the supplied USB cable into the **MICRO USB PORT** on the rear of the speaker. Then plug the Standard USB end into a USB port on a computer or USB wall charger.

- The **LED INDICATOR** on the speaker will turn RED when the speaker is charging
- The **LED INDICATOR** will turn OFF when the speaker is fully charged.



## PAIRING TO A BLUETOOTH DEVICE

1. Turn your Bluetooth device **OFF** entirely and then turn it back **ON** to refresh the device's Bluetooth memory.
2. Find the Bluetooth menu in your device and make sure the Bluetooth function is turned **ON** (refer to your device's user manual for instructions on finding the Bluetooth menu).
3. Turn the **A5BS ON** using the **ON / OFF SWITCH**. The **LED INDICATOR** will blink BLUE about 2 times per second, indicating the speaker is ready to be paired.
4. On your device, perform a Bluetooth "device discovery" to add the **A5BS** as a new device.
5. When the speaker is discovered your device will display "**A5BS**" in the Bluetooth menu.
6. If your Bluetooth device asks for a password, enter "0000" and the device will now pair with the speaker and be ready to use.
  - **NOTE:** The **LED INDICATOR** will flash BLUE about once every 3 seconds when the speaker has successfully paired with your device.
7. If supported by your device's menu, set the A5BS as "set as authorized" or "add to trusted devices".
  - **NOTE:** Keep the Bluetooth function on your device **ON**, to insure the speaker can automatically pair with your device the next time the speaker is turned **ON**.

## PLAYING MUSIC

After successfully pairing the speaker with your Bluetooth device, you can begin playing music simply by choosing the song you wish to hear on your device's menu system (refer to your device's user manual for instructions on playing music)

All Volume & Playback controls (Play, Pause, Skip + / -, etc.) are controlled directly on your Bluetooth device.

## USING NON-BLUETOOTH DEVICES

If you wish to use a device that does not have Bluetooth functionality with the **A5BS**, simply connect one end of the supplied 3.5mm Audio Cable into the Headphone Jack of your device and the other end into the **3.5mm AUDIO INPUT** on the **A5BS**.

**NOTE:** When using the **3.5mm AUDIO INPUT** the Bluetooth functions of the **A5BS** are not available and the **LED INDICATOR** will turn OFF. To resume Bluetooth operations simply unplug the cable from the **3.5mm AUDIO INPUT** and the **A5BS** will automatically re-pair with your Bluetooth device.

## **TROUBLESHOOTING**

1. **Speaker will not turn ON**
  - a. Make sure the **ON / OFF SWITCH** is set to the **ON** position.
  - b. Charge the battery
2. **Speaker will not Pair**
  - a. Turn your Device **OFF & ON** again to refresh the Bluetooth Memory
  - b. Turn the speaker **OFF & ON** again to attempt to re-pair with your device
  - c. Try pairing another Bluetooth device
3. **No Sound**
  - a. Make sure the volume on your device is not set to "0" or Mute
  - b. Make sure there is nothing plugged into the **3.5mm AUDIO INPUT**

**For Assistance call 1-855-994-2825 or visit [www.sibrandssupport.com](http://www.sibrandssupport.com)**



### **LIMITED 90-DAY WARRANTY**

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized ATAK dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

Our Customer Support Center is available Monday - Saturday (10:00AM to 7:00PM EST) for technical assistance or troubleshooting. To contact us, please call 1-855-994-2825, or visit [www.sibrandssupport.com](http://www.sibrandssupport.com).

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product, including the antenna. Damage to any external devices such as smartphones, tablets, and/or other devices are not covered nor is the cost incurred in shipping the unit for warranty repair or exchange. Under no circumstances shall ATAK be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

**UNDER NO CIRCUMSTANCES WILL ATAK BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.