



SLIMLINE PHONE

Model: EPH1010



**PLEASE READ THIS USER MANUAL COMPLETELY BEFORE
OPERATING THIS UNIT AND RETAIN THIS BOOKLET FOR
FUTURE REFERENCE.**

Setup

Ringer ON/OFF

To turn the Ringer ON/OFF use the Ringer Switch on the Left side of the handset.

Adjusting the Handset Volume

To adjust the Volume of the handset, simply use the Volume Control Switch on the Right side of the handset.

Tone/Pulse Setting

To adjust the Tone/Pulse Setting, simply use the Tone/Pulse Switch on the Right side of the handset.

Using the Memory Function

You can store up to 10 frequently used phone numbers in the phone's internal memory by assigning the desired phone number to one of the number buttons (0-9). Follow the steps below to Store and/or Call a number from the internal memory.

Storing a Number in the Memory

- Step 1: Pick up the handset so it is off the hook
- Step 2: Press the [**STORE**] button
- Step 3: Dial the phone number you wish to store in the memory
- Step 4: Press the [**STORE**] button again
- Step 5: Press the desired number button (**0-9**) where you wish to store the phone number
- Step 6: Press the [**STORE**] button again to confirm

Calling a Number from the Memory

- Step 1: Pick up the handset to make a call
- Step 2: Press the [**MEMO**] button
- Step 3: Press the number button (**0-9**) where you have previously programmed the phone number you wish to call. The phone will automatically begin the call.



LIMITED 90-DAY WARRANTY

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized ETEC dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

For technical support, visit our website www.sibrandssupport.com or call the ETEC Technical Support Center for technical assistance or troubleshooting at 1-855-994-3832, Monday to Saturday, 10:00AM to 7:00PM EST.

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product. Damage to any external media such as DVD & CD discs, and/or USB or other memory devices are not covered nor is the cost incurred in shipping the unit for warranty repair or exchange. Under no circumstances shall ETEC be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

UNDER NO CIRCUMSTANCES WILL ETEC BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.