



B110



INSTRUCTION MANUAL

Charging the Battery

Before using this product, fully charge the **B110** headset unit by plugging the charger into an AC outlet and inserting the connection pin into the Charging Port on the headset. The LED will turn BLUE when the battery is fully charged.


Headset Functions

1. Power ON your headset:

Turn the **POWER** switch to the **ON** position.
The blue indicator flashes four times.

2. Power OFF your headset:

Turn the **POWER** switch to the **OFF** position.
The red indicator flashes twice and the power will turn off.



Pairing the B110 Headset to Your Phone:

1. Turn your phone **OFF** entirely and then turn it back **ON** to refresh its Bluetooth memory.
2. Find the Bluetooth menu in your mobile phone turn the Bluetooth function **ON**. (Check your mobile phone user guide)
3. With the **B110 POWER OFF** hold the headset 12" inches away from your mobile phone and turn the **POWER** switch to the **ON** position. After a few seconds the LED light flashes blue and red alternating which indicates your headset is in **PAIRING MODE** and is now ready to be "paired" with your Bluetooth Mobile Phone.
4. On your phone, perform a Bluetooth "device discovery" to add the **B110** headset as a new device. It only takes a few seconds to search & find the **B110** Bluetooth headset.
5. When the **B110** headset is discovered (found) the phone will display "**B110**"
6. If prompted by your phone to enter a code, enter; "**0000**" and the phone will now pair with the headset and be ready to use.
7. If supported by your phone menu, set the **B110** as "set as authorized" or "add to trusted devices".
8. Keep the Bluetooth function on your phone **ON** with your phone near, the headset will automatically pair.
9. If the pairing is not successful, the headset will shortly return to the standby mode. Please repeat the process to try the pairing again.
10. Refer to your phones User Manual for any additional steps.
11. To pair a second device, turn the first phone's Bluetooth function, and the **B110** headset, **OFF** and repeat steps 3-10 using the second device.

Note: To conserve power, the unit automatically turns off when not paired with your Bluetooth Phone.

For Assistance please call 1-855-994-8364. Do NOT return this product to your retailer.

Operating the Headset:

1. To ANSWER or END a call:

Press the **FUNCTION** button once when there is an incoming call to answer. Press the **FUNCTION** button once again to end the call.
If your phone supports Voice Commands* (see your phones user guide) simply say "YES" to answer the call.

2. To REJECT* a call:

Press and Hold the the **FUNCTION** button (approx. 2-3 seconds) when there is an incoming call you want to ignore and send it to your voicemail.
If your phone supports Voice Commands* (see your phones user guide) simply say "NO" to reject the call.

3. To REDIAL* the last call:

Press the **FUNCTION** button twice.

4. To activate VOICE DIALING*:

While connected to your phone, Press and release the **FUNCTION** button and say the name of the person you wish to call when you hear a prompt. Note: Voice commands must already be recorded into your phone for this function to operate (see your phones user guide)

5. To adjust the VOLUME:

Press & Hold the **VOLUME +** or **VOLUME -** to adjust to the desired level.

6. To PLAY music & change the SONG / TRACK:

PLAY / PAUSE: Press the **PLAY / PAUSE** button to begin playing music. Press **PLAY / PAUSE** again to **PAUSE** music.

SKIP TO NEXT SONG: Press and immediately release the **NEXT +** button to skip forward to the next song/track.

SKIP TO PREVIOUS SONG: Press and immediately release the **PREVIOUS -** button to skip backward to the previous song/track.

* To use these functions, your phone/device must also support the Bluetooth Profile.

LED indicator chart

| | |
|-------------------------|---|
| Power on | Blue indicator blinks 4 times |
| Power off | Red indicator blinks 2 times |
| Standby mode | Blue indicator blinks twice every 8 seconds |
| Power Conservation mode | LED indicator does not blink |
| Pairing mode | Flashing Blue and Red Light |
| Active call | Blue indicator blinks rapidly |
| Low battery | Blinking Red Light |
| Charging | Steady Red Light |
| Charging complete | Steady Blue Light |

Note: Power Conservation mode means your headset maintains a connection with your phone but is conserving power and will wake up when any function is activated.

Specifications

| | |
|------------------------------|---|
| Bluetooth Specifications | V4.0 |
| Bluetooth Profiles Supported | Headset, Handsfree, Multi-point, A2DP, AVRCP |
| Transmission Power | Class 2 |
| Operation Range | Up to 10 Meters |
| Frequency Range | 2.402~2.4835 GHz |
| Battery | Built-in Rechargeable 3.7V Li-polymer Battery |
| Charging Voltage | DC4.75-5.25V |
| Charging Time | About 2 hours |
| Talk Time* | Up to 8 hours |
| Standby Time* | Up to 200 hours |
| Weight | About 22g |
| | |
| | |

*May vary due to user's operation mode and device settings



LIMITED 90-DAY WARRANTY

We warrant this product to be free from defects in material and workmanship under normal use for a ninety-day period from the original date of purchase from an authorized THUNDERDOG dealer.

Should you be missing any of the included accessories or other components (screws, pieces, etc.), please contact the Customer Support Center to secure a replacement. It is not necessary to bring the unit back to the store. When calling, please reference the parts list found in the Instruction Manual to help us accurately identify the missing parts and promptly provide replacements.

We will replace the unit free of charge should it become defective under this warranty, providing you, the original purchaser, have your original dated sales receipt.

To obtain warranty service or replacement within the ninety-day warranty period, please return the product with all parts and accessories along with your original dated store receipt to the original place of purchase and the unit will be exchanged at no charge. It is not necessary to contact the manufacturer for warranty replacement.

Our Customer Support Center is available Monday - Saturday (10:00AM to 7:00PM EST) for technical assistance or troubleshooting. To contact us, please call 1-855-994-8364.

This warranty applies only under conditions of normal use. Our products are not intended for outdoor use.

There are no consumer serviceable parts contained in this product and any attempt by the owner to service or repair the unit will immediately void all warranty coverage.

This warranty does not cover any product which has been subject to damage due to an act of nature, misuse, neglect, accident, abuse, commercial use, or modification of, or to, any part of the product, including the antenna. Damage to any external media such as DVD & CD discs, and/or USB or other memory devices are not covered nor is the cost incurred in shipping the unit for warranty repair or exchange. Under no circumstances shall THUNDERDOG be liable for any loss (direct, indirect, incidental, foreseen, unforeseen, special or consequential) or for any damage arising out of, or in connection with, the use of this product.

UNDER NO CIRCUMSTANCES WILL THUNDERDOG BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

This warranty does not cover re-manufactured, refurbished, or repaired units, or any products sold 'As Is'.

This warranty is valid only to the original purchaser of the Product in the United States and Canada and grants specific legal rights.